

散装液体袋安全使用检查表

Checklist of Safety Items in Using Flexi-tanks

Form 1

Items for Checking the Container

Tick if YES

1. 集装箱使用时间小于3 年

Container used for less than 3 years

2. 集装箱箱板承重至少30480公斤

Container floor bearing capacity no less than 30,480 kg

3. 箱体壁板及底部无尖锐物

No sharp stuff on the side walls and the floor

4. 门闩、门铰链、门锁杆和把手柄状态良好

Bolts, gemels, lock levers and handles in good shape

5. 地板彻底清扫干净

Completely cleaned floor

6. 焊接区域和修补处使用胶带完全密封

All welded and mended area fully sealed by adhesive tape

<input type="checkbox"/>
<input type="checkbox"/>
<input type="checkbox"/>
<input type="checkbox"/>
<input type="checkbox"/>
<input type="checkbox"/>

检查人签名

检查时间

Signature of Inspector

Date of Inspection

散装液体袋安全使用检查表

Checklist of Safety Items in Using Flexi-tanks

Form 2

Items for Checking the Flexi-tank Installation

Tick if YES

<p>1. 保护托板正确安装并且位置正确</p> <p style="padding-left: 20px;">Bulk head correctly installed and in the right position</p>	<input type="checkbox"/>
<p>2. 重载瓦楞纸板衬于地板和箱壁 (包括保护托板处最小高度为1400mm)</p> <p style="padding-left: 20px;">Cardboard placed on the floor and side walls (no lower than 1400mm around the side walls)</p>	<input type="checkbox"/>
<p>3. 液体袋外包装无破损</p> <p style="padding-left: 20px;">No damage to the outside packing of the flexi-tank</p>	<input type="checkbox"/>
<p>4. 液体袋正确折叠及放置</p> <p style="padding-left: 20px;">Flexi-tank properly folded and placed</p>	<input type="checkbox"/>
<p>5. 通气阀门紧固且无损坏</p> <p style="padding-left: 20px;">Ventilation valve well fastened and undamaged</p>	<input type="checkbox"/>
<p>6. 软管及其配件紧固且无破损</p> <p style="padding-left: 20px;">Pipe and its accessories well fastened and undamaged</p>	<input type="checkbox"/>
<p>7. 左侧箱门紧闭-锁定</p> <p style="padding-left: 20px;">Left door of the container well locked</p>	<input type="checkbox"/>
<p>8. 液体袋警告标签粘贴于左侧箱门外面</p> <p style="padding-left: 20px;">Warning Sign stuck on outside wall of the left door</p>	<input type="checkbox"/>
<p>9. 检查及安装核对表放置于文件袋内并且粘贴于右侧箱门里面</p> <p style="padding-left: 20px;">Checking reports filed in a packet and stuck on the inside wall of the right door</p>	<input type="checkbox"/>

检查人签名

检查时间

Signature of Inspector

Date of Inspection

散装液体袋安全使用检查表

Checklist of Safety Items in Using Flexi-tanks

Form 3

Items for Checking the Loading Process

Tick if YES

1. 集装箱保持水平 Container kept level	
2. 装填接口和软管配件/阀门无缝连接 Loading spout and pipe/valve seamlessly connected	
3. 装料速度均匀 Loading at constant speed	
4. 液袋上的相关配件保持原来的位置 Position of the flexi-tank accessories unchanged	
5. 装料完成后，确保阀门锁定、阀帽紧固 Valve locked and bonnet fixed after loading	
6. 阀帽用原配的柔性材料缠绕保护以避免和袋体直接接触 The bonnet fully covered with enclosed soft material to avoid its direct contact with the flexi-tank	
7. 软管配件用预备好的带子安全地系于液体袋上 Pipe accessories well fastened to the flexi-tank with the enclosed belt	
8. 检查有效载荷，不要超过允许液体袋的最大载重量 Actual loading not exceeding maximum capacity of the flexi-tank	

检查人签名

检查时间

Signature of Inspector

Date of Inspection

散装液体袋安全使用检查表

Checklist of Safety Items in Using Flexi-tanks

Form 4

Items for Checking of the Unloading Process

Tick if Yes

1. 左侧箱门处于锁定状态 Left door properly locked	
2. 软管配件/阀门正确连接至卸料导管/接口 Pipe and valve seamlessly connected with the unloading spout	
3. 软管及其配件状态良好且未承受过度张力 Pipe and its accessories in good shape and not bearing excessive tensile force	
4. 残留的货物要从液体袋中完全抽空 All residual cargo completely pumped out	

检查人签名

检查时间

Signature of Inspector

Date of Inspection